

# Specs: 26.00Specs23

## Waterproofing External/Internal walls - Bricks, Cement Blocks, Concrete, Render etc

#### Products required

- MAXJOINT ELASTIC or MAXREST
- MAXSEAL FLEX or MAXSEAL
  FOUNDATION

### <u>Method</u>

- 1. Prepare area to be treated by removing any loose materials ensuring a clean and sound surface.
- 2. Any damage to the surface should be repaired using **MAXREST**.
- 3. Any missing mortar can be replaced with either MAXREST or **MAXJOINT ELASTIC**.
- 4. Thoroughly wet the entire surface before applying coating.
  - a. USE MAXSEAL FOUNDATION to seal all previously uncoated areas. Texture as required. Two coats required.

OR:

- b. Use **MAXSEALFLEX** to coat previously treated surfaces or surfaces subject to movement.
- 5. Use **DRIZORO** products as finish coat, texture or paint, tile, render as required.

## If Efflorescence present contact Office before application of Waterproofing.



Wet surface before application.



Apply by brush ...





... finish using texture roller.

© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved. Address: Unit 4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA Tel: +61 2 9771 0011 Fax: +61 2 9771 0111 Email: admin@swppl.com.au National Hotline: 1300 303 301 http://swppl.com.au/