



Specs: 26.21 Specs23

Waterproofing Sewer Access Chambers.

Products required

- **MAXSEAL FLEX**

Method

EXTERNAL:

1. Fill all suspect areas using Maxrest
2. Wet thoroughly apply **MAXSEAL FLEX** in 2 coats @ 1Kg/coat/m2 wet between coats

INTERNAL:

1. Remove all render, paint or other material from substrate.
2. **MAXPLUG** all major waterflow.
3. Remove all residue of other materials.
4. Wet area and apply **MAXSEAL FLEX**
5. Allow to cure overnight and seal any remaining water ingress using **MAXPLUG**.
6. Apply second coat of **MAXSEAL FLEX**
7. 2 coats @ 1Kg/coat/m2 wet between coats

© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved.

Address: Unit 4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA

Tel: +61 2 9771 0011

Email: admin@swppl.com.au

National Hotline: 1300 303 301 <http://swppl.com.au/>