

CLEARCOAT APPLICATION ON TILED SURFACES:

To waterproof leaking tiled balconies. We recommend the following: -



a. Remove all loose material as well as cleaning out missing grout areas – if efflorescence, apply Efflorescence Rid using Efflorescence-rid sprayed via a low-pressure sprayer.



- b. Remove all loose & damaged grout, allow area to dry completely
- c. Repeat the application of Efflorescence rid until foaming stops which may require more than 3 passes depending on the amount of efflorescence present.
- d. On completion of last pass with Efflorescence-Rid wash area with clean water. Allow area to dry completely.
- e. Using a "squeeze bottle" pour Sealtight into grout lines and screed where tile grout has been removed, to the point of flooding the screed.
- f. Allow the Sealtight to dry over a min of 24 hours.
- g. Re-apply tile grout and allow to dry.
- h. Once tile grout is dry, coat the entire balcony with CLEARCOAT. Ensure that clearcoat has a min of 24 hours to dry before getting wet.

Suitable surfaces: -sandstone, tiles • pavers• terracotta tiles, timber, concrete, bricks and most masonry surfaces, WET AREAS, top coating timber floors.

Always apply to a completely dry surface free of dampness and/or moisture.

Good preparation is essential.

Surfaces must be dry, clean, sound, stable, and free of dust, grease, loose, flaking, friable material and other contamination and substances. Surface to be wash with detergent and/or bleach and washed off with clean water and allowed to dry thoroughly. Moss and mould must be removed with a solution of 1-part bleach to 2-parts water, and then washed off with clean water. Allow to thoroughly dry.

All technical bulletins are available on our website <u>www.swppl.com.au</u>. Please do not hesitate to contact us should further information be required.

Bruce Leslie - Mobile 0406 137 701 bruce@swppl.com.au

PO Box 694, Padstow NSW 2211, Australia Phone: +61 (2) 9771 0011