

Specs:26.00Specs23

Rising Damp-Waterproofing External/Internal walls - Bricks, Cement Blocks, Concrete, Render etc

Products required

- MAXJOINT ELASTIC or MAXREST
- MAXSEAL FLEX or MAXSEAL FOUNDATION

<u>Method</u>

- Prepare area to be treated by removing any loose materials ensuring a clean and sound surface.
- 2. Any damage to the surface should be repaired using **MAXREST**.
- 3. Any missing mortar can be replaced with either MAXREST or **MAXJOINT ELASTIC**.
- 4. Thoroughly wet the entire surface before applying coating.
 - a. USE MAXSEAL
 FOUNDATION to seal all
 previously uncoated areas.
 Texture as required. Two
 coats required.

OR:

- Use MAXSEALFLEX to coat previously treated surfaces or surfaces subject to movement.
- 5. Use **DRIZORO** products as finish coat, texture or paint, tile, render as required.

If Efflorescence present contact Office before application of Waterproofing.



Wet surface before application.



Apply by brush ...





... finish using texture roller.

© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved.

Address: Unit 4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA

Tel: +61 2 9771 0011 **Fax:** +61 2 9771 0111

Email: admin@swppl.com.au

National Hotline: 1300 303 301 http://swppl.com.au/