

## Specs: 26.17Specs23

<u>Treatment of walls around</u> <u>Windows and Doors, Parapets, etc.</u> <u>Areas of Rising Damp – Below</u> <u>Dampcourse,</u>



## Products required

- MAXQUICK ROLL
- MAXREST

## <u>Method</u>

- 1. Prepare area to be treated by removing any loose materials ensuring a clean and sound surface.
- 2. Any damage to the surface should be repaired using **MAXREST**.
- Thoroughly wet the entire surface before applying coating. Use MAXQUICK ROLL on previously uncoated surfaces. Single coat application.

**MAXQUICK ROLL** is supplied as a cement powder that mixes with water. This mixture is then brushed onto a pre-dampened (wet) surface.

4. Once coated the surface should be allowed minimum 24 hours before final paint or texture coating is applied.



To prevent flaking, peeling and discolouring of painted surfaces.



Here rising damp is causing paint to blister on the bottom course below the dampcourse.

*Maxquick Roll* is ideal for use under Morrocca & other acrylic textured coatings and painted finishes or, external cladding to provide a dry surface. DO NOT USE to waterproof areas subject to negative water flow or standing water.

© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved. Address: Unit 4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA Tel: +61 2 9771 0011 Email: admin@swppl.com.au National Hotline: 1300 303 301 http://swppl.com.au/