



# Specs: 26.055Specs23

## Waterproofing Multi Panels

### Products required

- **MAXSEAL FLEX**
- **MAXMESH**

### Method

1. Prepare area to be treated by removing any loose materials ensuring a clean and sound surface. If surface previously painted all paint must be removed.
2. Wet and coat joint area with **MAXSEAL FLEX**, according to product specifications and place 50mm reinforcing **MAXMESH** incorporating it into the first coat of MAXSEAL FLEX. Allow to cure over night.
3. Wet surface and apply a coat of MAXSEALFLEX at the rate of 1kg/m<sup>2</sup> and ensure coverage over entire area..
4. Leave for minimum of 4 hrs or maximum of overnight before placing topping.
5. As soon as topping can be walked on, wet surface, apply a coat of MAXSEALFLEX at the rate of 1kg/m<sup>2</sup> .
6. Wet surface and apply second coat of **MAXSEAL FLEX**, over entire area (at 1kg/m<sup>2</sup>) according to product specifications. (not less than 14 hrs)
7. Leave for 5 days minimum prior to application of other finishes or processes..

© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved.

Address: Unit 4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA

Tel: +61 2 9771 0011

Email: [admin@swppl.com.au](mailto:admin@swppl.com.au)

National Hotline: 1300 303 301 <http://swppl.com.au/>

***Don't just waterproof it... DRIZORO it!***  
Visit: [www.swppl.com.au](http://www.swppl.com.au)