



Specs: 26.14Specs23


Waterproofing Inside Planter Boxes

Products required

- **MAXREST** or **MAXJOINT ELASTIC**
- **MAXSEAL FLEX OR MAXSEALFLEX -M**
- **MAXMESH**

Method

1. Prepare area to be treated by removing any loose materials ensuring a clean and sound surface.
2. Any damage to the surface should be repaired using **MAXREST**.
3. Any missing mortar can be replaced with either **MAXREST** or **MAXJOINT ELASTIC**.
4. In the corner where the wall meets the concrete slab a coving of **MAXREST** should be formed.
5. Thoroughly wet the entire surface before applying coating.
6. Two coats of **MAXSEAL FLEX** should be applied according to product brochure leaving overnight between coats.
7. Apply **MAXMESH** on the corner joints to provide extra strength.
8. After second coat has been applied leave for 4-5 days before filling planter box.



© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved.

Address: Unit 4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA

Tel: +61 2 9771 0011

Email: admin@swppl.com.au

National Hotline: 1300 303 301 <http://swppl.com.au/>