



Specs: 16.155Specs23

Waterproofing Brick or Block walls prior to the application of render.

Products required

- **MAXSEAL FOUNDATION**
- **MAXSEALFLEX**

Method

1. Thoroughly clean the surface to remove any moss/algae or any traces of paints or efflorescence. This can be achieved by pressure washing if necessary.
2. Coat the entire surface with two coats of MAXSEAL FLEX OR FOUNDATION as per the manufacturers specifications. Remember;
 - a. MAXSEALFLEX OR FOUNDATION must be applied to a wet surface.
 - b. MAXSEALFLEX OR FOUNDATION is a two-coat system.
 - c. Leave first coat for a minimum of 8 hours before applying second coat.
 - d. Second coat should be applied across(hash) direction to the first.
3. Leave the second coat minimum 16 hours before rendering. We do not recommend allowing more than 48 hours between the second coat and the render being applied.
4. We recommend that before applying render a "Flick Coat" made from a mix of cement and Bondcrete is applied to the surface to aid adhesion.
5. Apply render as normal. Remember, because the render is being applied to a waterproof surface the cure time will be extended as no moisture is absorbed into the wall.
6. If movement is evident use MAXSEALFLEX in place of Maxseal FOUNDATION

If Efflorescence present

Please contact our national hotline for more information or clarification, prior to application of waterproofing.

1300 303 301

The information contained in this publication is based on laboratory testing and on our own experience and of the experience of our applicators. Any use of the data in this document beyond the purposes expressly specified will not be the company's responsibility unless authorized by us.

© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved.

Address: Unit 4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA

Tel: +61 2 9771 0011

Email: admin@swppl.com.au

National Hotline: 1300 303 301 <http://swppl.com.au/>