



Specs: 26.20Specs23


Sealing Wall / Floor Joints.

Products required

- **MAXPLUG/Maxjoint Elastic**
- **MAXSEAL FLEX**
- **MAXMESH**

Method

1. Cut a channel at the base of the wall minimum 30mm wide and deep.
2. If water flow fill up this newly created void with **MAXPLUG**
3. If no water flow fill using Maxjoint Elastic
4. Leave to cure for 5-10 minutes.
5. Coat the area 1-2 course up the wall, the **MAXPLUG/Maxjoint** and onto the concrete floor (150-200mm) with **MAXSEAL FLEX** (2 coats) to prevent any water migration.
6. The **MAXSEAL FLEX** will adhere to all three surfaces.
7. WET surface, APPLY **MAXSEAL FLEX**, install **MAXMESH**, allow to cure min. 14 hrs
8. WET surface, APPLY second coat **MAXSEAL FLEX** over Mesh.



© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved.
Address: Unit4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA
Tel: +61 2 9771 0011
Email: admin@swppl.com.au
National Hotline: 1300 303 301 <http://swppl.com.au/>