



Specs: 26.22Specs23

TRAFFIC SURFACING and Waterproofing – Horizontal Surfaces

Products required

- **MAXSEAL SUPER/FOUNDATION**
- **MAXSEAL FLEX TRAFFIC**

ENSURE that the substrate is sound and free of cracks.

Method

1. Remove all render, paint or other material from the substrate.
2. On ACC surfaces (HEBEL) surface to be coated must be primed first with a single coat of **MAXSEAL FOUNDATION** or **SUPER** mixed to a slurry (2 parts powder to 1 part water).
3. This will seal the surface in preparation for finish coats. WET surface before applying prime coat.
4. Leave to cure overnight.
5. Wet surface, apply first coat **MAXSEAL TRAFFIC**
 - a. 3 to 6 hours between coats
 - b. Embed Maxmesh in first coat over Floor/wall and control joints.
 - c. Apply second coat 48 hours to traffic.
6. **MAXSEAL TRAFFIC**. Remember to wet surface prior to application of coats.
7. Leave for 24-48 hours to cure.
8. Can be applied to Hardie's Secura™ Flooring as trafficable, waterproof coating.

NOTE: First coat must be applied by brush/broom, second coat can be applied by brush/broom or roller depending on desired finish.

IMPORTANT CAUTION: DO NOT LEAVE FREE WATER (puddles) ON SURFACE.

© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved.

Address: Unit 4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA

Tel: +61 2 9771 0011

Email: admin@swppl.com.au

National Hotline: 1300 303 301 <http://swppl.com.au/>