



# Specs: 26.25Specs23


## Waterproofing Watertanks, Fishponds & Water Features.

### Products required

- **MAXPLUG or MAXREST**
- **MAXSEAL FLEX**
- **MAXMESH**

### Method

1. Prepare area to be treated by removing any loose materials ensuring a clean and sound surface.
2. Any damage to the surface should be repaired using **MAXPLUG or MAXREST**.
3. Thoroughly wet the entire surface before applying the **MAXSEAL FLEX** coating by brush.
4. A coving should be placed in the corner joint using either a non-shrink grout or **MAXREST**.
5. A reinforcement mesh, **MAXMESH**, can be used on corner joints to provide added strength. The mesh is pushed into the first coat of **MAXSEALFLEX**.
6. Construction joints will require flexible. **Maxjoint Elastic**
7. Leave overnight before applying second coat of **MAXSEAL FLEX**.
9. Leave for 14 days to cure before filling pond with water. Plants and pebbles can be added for decoration.



Basic bricked up area on concrete slab to be used as a water feature.



Apply by brush after wetting surface.



Leave overnight between coats.



Left for 14 days before pond was filled.