



# Specs: 26.28Specs23

## SEALING FRACTURES IN SUSPENDED CONCRETE SLABS

### Products required


- **MAXJOINT ELASTIC**
- **MAXSEAL FLEX**

### Method

1. Prepare area to be treated by removing any loose materials ensuring a clean and sound surface.
2. Using a grinding wheel, open the fracture to a width of 10mm and a minimum depth of 10mm.
3. Remove any debris from the newly formed void and moisten with primer (part A ) of **MAXJOINT ELASTIC**.
4. Apply **MAXJOINT ELASTIC** to the void, Mixing- 1 part liquid to 1 part powder- as per technical bulletin 156:01.
5. Where the area is subject to multiple cracks.

**NON-Traffic:** Apply 2 coats of MAXSEALFLEX

**EXPOSED TO TRAFFIC:** It is recommended that the entire slab be coated with **MAXSEAL TRAFFIC**.



© Scientific Waterproofing Products Pty Ltd. ABN: 155 659 948 All rights reserved.

Address: Unit 4/92 Bryant Street, Padstow, NSW 2211, AUSTRALIA

Tel: +61 2 9771 0011 Fax: +61 2 9771 0111

Email: [admin@swppl.com.au](mailto:admin@swppl.com.au) National Hotline: 1300 303 301

<http://swppl.com.au/>